

Konfiguracja routera Vigor 2800 do pracy z Neostradą

Po zalogowaniu się do routera należy przejść do punktu Internet Access wybrać PPPoE/PPPoA.

W poszczególne pola należy wpisać (jak na obrazku):

VPI – 0

VCI – 35

Encapsulating Type – VC MUX

Protocol – PPPoA

Modulation - G.DMT

ISP Name – dowolna nazwa

Username – użytkownik otrzymany podczas rejestracji usługi Neostrada

Password - hasło otrzymane podczas rejestracji usługi Neostrada

DrayTek Vigor2800 series - Microsoft Internet Explorer

Plik Edycja Widok Ulubione Narzędzia Pomoc

Wstecz Wyszukaj Ulubione Multimedia

Adres http://192.168.1.1/ Przejdz

Łącząc Comp-Art Shift RMA Tech Data GG-RPL Edimax-NL Edimax-TW Cisco

Vigor2800 Series ADSL2/2+ Router

DrayTek www.draytek.com

Quick Start Wizard
Online Status

Internet Access

- ▶ PPPoE / PPPoA
- ▶ MPoA (RFC1483/2684)
- ▶ Multi-PVCs

LAN
NAT
Firewall
Applications
VPN and Remote Access
Certificate Management
VoIP
Wireless LAN
System Maintenance
Diagnostics

All Rights Reserved.

Status: Ready

OK

Internet

PPPoE/PPPoA Client Enable Disable

DSL Modem Settings

Multi-PVC channel Channel 1

VPI 0

VCI 35

Encapsulating Type VC MUX

Protocol PPPoA

Modulation G.DMT

PPPoE Pass-through

For Wired LAN

For Wireless LAN

ISP Access Setup

ISP Name neostrada

Username rejestracja@neostrada

Password [redacted]

PPP Authentication PAP or CHAP

Always On

Idle Timeout 180 second(s)

IP Address From ISP WAN IP Alias

Fixed IP Yes No (Dynamic IP)

Fixed IP Address

* : Required for some ISPs

Default MAC Address

Specify a MAC Address

MAC Address : 00 . 50 . 7F . D2 . E5 . 81

Index(1-15) in **Schedule** Setup:

[] , [] , [] , []

R+PL Computer Systems Sp. z o.o. - Serwis
ul. Fordońska 85a
85-719 Bydgoszcz
tel. 052 3705633